



Product and Vehicle Matrix

| Vehicle Model | Wheel Base (mm) | Floor Length (mm) | Floor Width (mm) | Floor Width at Arches (mm) | SmartFloor Length (mm) |
|------------------------------------|-----------------|-------------------|------------------|----------------------------|------------------------|
| Citroen Dispatch / Jumpy | 2824 | 2059 | 1600 | 1220 | 3360 |
| Citroen Relay / Jumper SWB | 2850 | 2510 | 1808 | 1388 | 3360 |
| Citroen Relay / Jumper MWB | 3200 | 2860 | 1808 | 1388 | 3360 |
| Citroen Relay / Jumper LWB | 3700 | 3360 | 1808 | 1388 | 3360 |
| Fiat Scudo | 2824 | 2059 | 1600 | 1220 | 3360 |
| Fiat Ducato SWB | 2850 | 2510 | 1808 | 1388 | 3360 |
| Fiat Ducato MWB | 3200 | 2860 | 1808 | 1388 | 3360 |
| Fiat Ducato LWB | 3700 | 3360 | 1808 | 1388 | 3360 |
| Ford Transit SWB | 2930 | 2582 | 1762 | 1390 | 3360 |
| Ford Transit MWB | 3300 | 2949 | 1762 | 1390 | 3360 |
| Ford Transit LWB | 3750 | 3399 | 1762 | 1390 | 3360 |
| Ford Transit LWB Jumbo | 3750 | 4107 | 1762 | 1390 / 1153 | 4500 |
| Iveco Daily SWB | 3000 | 2600 | 1770 | 1320 | 3360 |
| Iveco Daily SWB (L) | 3000 | 3000 | 1770 | 1320 | 3360 |
| Iveco Daily MWB | 3300 | 3560 | 1770 | 1320 / 1030 | 4500 / 3700 spl.order |
| Iveco Daily LWB | 3950 | 4560 | 1770 | 1320 / 1030 | 4500 |
| LDV Maxus LWB | 3850 | 3320 | 1800 | 1355 | 3360 |
| Mercedes Benz Vito | 3200 | 2420 | 1770 | 1277 | 3360 |
| Mercedes Benz Vito Long | 3200 | 2670 | 1770 | 1277 | 3360 |
| Mercedes Benz Vito Extra Long | 3430 | 2850 | 1770 | 1277 | 3360 |
| Mercedes Benz Viano | 2900 | 1810 | 1770 | 1277 | 3360 |
| Mercedes Benz Sprinter SWB | 3000 | 2510 | 1740 | 1270 | 3360 |
| Mercedes Benz Sprinter MWB | 3550 | 3260 | 1740 | 1270 | 3360 |
| Mercedes Benz Sprinter LWB | 4025 | 4210 | 1740 | 1270 / 1022 | 4500 |
| Mercedes Benz Sprinter SWB (MY06) | 3250 | 2600 | 1780 | 1350 / 1228 | 3360 |
| Mercedes Benz Sprinter MWB (MY06) | 3665 | 3265 | 1780 | 1350 / 1228 | 3360 |
| Mercedes Benz Sprinter LWB (MY06) | 4325 | 4300 | 1780 | 1350 / 1228 | 4500 |
| Mercedes Benz Sprinter XLWB (MY06) | 4325 | 4700 | 1780 | 1350 / 1228 | 4700 |
| Nissan Primastar SWB | 3100 | 2400 | 1670 | 1268 | 3360 |
| Nissan Primastar LWB | 3500 | 2800 | 1670 | 1268 | 3360 |
| Nissan Interstar SWB | 3080 | 2710 | 1760 | 1382 | 3360 |
| Nissan Interstar MWB | 3580 | 3210 | 1760 | 1382 | 3360 |
| Nissan Interstar LWB | 4080 | 3710 | 1760 | 1382 | 4500 / 3700 spl.order |
| Peugeot Expert | 2824 | 2059 | 1600 | 1220 | 3360 |
| Peugeot Boxer SWB | 2850 | 2510 | 1808 | 1388 | 3360 |
| Peugeot Boxer MWB | 3200 | 2860 | 1808 | 1388 | 3360 |
| Peugeot Boxer LWB | 3700 | 3360 | 1808 | 1388 | 3360 |
| Renault Traffic SWB | 3100 | 2400 | 1670 | 1268 | 3360 |
| Renault Traffic LWB | 3500 | 2800 | 1670 | 1268 | 3360 |
| Renault Master SWB | 3080 | 2710 | 1760 | 1382 | 3360 |
| Renault Master MWB | 3580 | 3210 | 1760 | 1382 | 3360 |
| Renault Master LWB | 4080 | 3710 | 1760 | 1382 | 4500 / 3700 spl.order |
| Toyota Hi-Ace LWB | 3430 | 2780 | 1650 | TBA | 3360 |
| Vauxhall / Opel Vivaro SWB | 3100 | 2400 | 1670 | 1268 | 3360 |
| Vauxhall / Opel Vivaro LWB | 3500 | 2800 | 1670 | 1268 | 3360 |
| Vauxhall / Movano SWB | 3080 | 2710 | 1760 | 1382 | 3360 |
| Vauxhall / Movano MWB | 3580 | 3210 | 1760 | 1382 | 3360 |
| Vauxhall / Movano LWB | 4080 | 3710 | 1760 | 1382 | 4500 / 3700 spl.order |
| VW T5 Transporter / Caravelle | 3000 | 2543 | 1692 | 1244 | 3360 |
| VW T5 Transporter / Caravelle LWB | 3400 | 2943 | 1692 | 1244 | 3360 |
| VW LT SWB | 3000 | 2510 | 1740 | 1270 | 3360 |
| VW LT MWB | 3550 | 3260 | 1740 | 1270 | 3360 |
| VW LT LWB | 4025 | 4210 | 1740 | 1270 / 1022 | 4500 |
| VW Crafter SWB | 3250 | 2600 | 1780 | 1350 / 1228 | 3360 |
| VW Crafter MWB | 3665 | 3265 | 1780 | 1350 / 1228 | 3360 |
| VW Crafter LWB | 4325 | 4300 | 1780 | 1350 / 1228 | 4500 |
| VW Crafter LWB Maxi | 4325 | 4700 | 1780 | 1350 / 1228 | 4700 |

The above dimensions are meant for guidance only, please check with the respective vehicle manufacturers specifications before use.