

## **MAGIC SEATS INSTRUCTION SHEET**

Remove the seat cushions from both seats by pulling out the silver plungers mounted on hooks on each side of the seat frame.

Unlock the window side seat. Rotate the handle at the base of the seat back and then undo the two conical locks located at the base. The seat can now be rotated clockwise through 90 degrees and be pushed against the side of the coach. Now relock the handle and base locks.

Now unlock the aisle side wheelchair seat. At the rear of the base press down on the sprung loaded lock dog and at the same time lift the foot pedal up off the ratchet. This has unlocked the seat from the longitudinal plate. Now rotate the handle at the base of the seat back. This has unlocked the seat from the top horizontal plate.

Now slide the seat backwards until it meets the row of seats behind. Now slide the seat sideways towards the side of the coach until it hits the stop bolt. Re lock the handle.

The seats are now configured to take a wheelchair on board.

Once the wheelchair is in position slide the wheelchair seat forward until it reaches the plunger hole and the plunger drops in. Now tread on the rear foot pedal, which locks the seat in position.

Pull out the yellow sprung loaded plunger and lift until it engages the catch plate with locking slot.

Now pull out the two belts on the drums and attach onto the main wheelchair frame at the rear as low as possible. Manoeuvre the wheelchair against the seat back. Pull out the yellow sprung loaded plunger and move it away from the catch plate.

Tread on the foot pedal in an up and down motion to tension the belts and lock the wheelchair until secure. Apply wheelchair brakes.

Use the seat occupant belt around the wheelchair user.

